

Performing a search and backup with a Digi-Master DVR

All functions can be performed from the front of the DVR and will have a similar button layout to this:



Archive

Press Search

Green Squares around a date indicate there is recorded data for that date.




Each channel is broken down into half-hour segments in a 24 hour period.

Press Enter to Bring up the calender control and select a date. Then press Enter again.




You will now have control over the time indicator. Press Enter to playback from the time marker.



Recorded video will appear lighter blue.


If you know the exact date and time you can enter it directly Using the search by event feature.



Once the start button is selected all the matching recordings will appear in the search box.

Once you have found and viewed the footage you were looking for, insert the media (CD,DVD,USB Drive) you want to backup to and press the Archive button.

De-select any channels you do not need. Channels 1-8 are on page 1 while 9-16 are on page 2.



Channels 1-8 are on page 1
Channels 9-16 are on page 2.